

Synapse

TXT06

SDI TEXT INSERTER

Synapse

TECHNICAL MANUAL

TXT06

SDI TEXT INSERTER



Lange Wagenstraat 55

NL-5126 BB Gilze

The Netherlands

Phone: +31 161 850 450

Fax: +31 161 850 499

E-mail: Info@axon.tv

Web: www.axon.tv



WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRICAL SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE

- ALWAYS disconnect your entire system from the AC mains before cleaning any component. The product frame (SFR18 or SFR04) must be terminated with three-conductor AC mains power cord that includes an earth ground connection. To prevent shock hazard, all three connections must always be used.
- NEVER use flammable or combustible chemicals for cleaning components.
- NEVER operate this product if any cover is removed.
- NEVER wet the inside of this product with any liquid.
- NEVER pour or spill liquids directly onto this unit.
- NEVER block airflow through ventilation slots.
- NEVER bypass any fuse.
- NEVER replace any fuse with a value or type other than those specified.
- NEVER attempt to repair this product. If a problem occurs, contact your local Axon distributor.
- NEVER expose this product to extremely high or low temperatures.
- NEVER operate this product in an explosive atmosphere.

Warranty: Axon warrants their products according to the warranty policy as described in the general terms. That means that Axon Digital Design BV can only warrant the products as long as the serial numbers are not removed.

Copyright © 2001 – 2006 AXON Digital Design B.V.

Date created: 13-04-04

Date last revised: 11-11-06

Axon, the Axon logo and Synapse are trademarks of Axon Digital Design B.V.

This product complies with the requirements of the product family standards for audio, video, audio-visual entertainment lighting control apparatus for professional use as mentioned below.



EN60950	Safety
EN55103-1: 1996	Emission
EN55103-2: 1996	Immunity

Axon Digital Design TXT06



Tested To Comply
With FCC Standards

FOR HOME OR OFFICE USE

This device complies with part 15 of the FCC Rules
Operation is subject to the following two conditions:
(1) This device may cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Table of Contents

Chapter 1	Introduction to Synapse	3
	An introduction to Synapse	3
	Local Control Panel	3
	Remote Control Capabilities	3
Chapter 2	Unpacking and Placement	4
	Unpacking	4
	Locating the card	4
Chapter 3	A Quick Start	5
	When powering-up	5
	Default settings	5
	Changing parameters and settings	5
	Front Panel Control	5
	Example of changing parameter using Front Panel control	6
	Synapse SetUp Software	7
	Menu Structure Example	7
Chapter 4	The TXT06 card	8
	Introduction	8
Chapter 5	Settings Menu	9
Chapter 6	Status Menu	10
Chapter 7	Events	11
Chapter 8	LED Indication	13
Chapter 9	Block Schematic	14
Chapter 10	Connector panel	15

1 Introduction to Synapse

An Introduction to Synapse

Synapse is a modular system designed for the broadcast industry. High density, intuitive operation and high quality processing are key features of this system. Synapse offers a full range of converters and processing modules. Please visit the AXON Digital Design Website at www.axon.tv to obtain the latest information on our new products and updates.

Local Control Panel

The local control panel gives access to all adjustable parameters and provides status information for any of the cards in the Synapse frame, including the Synapse rack controller. The local control panel is also used to back-up and restore card settings. Please refer to the RRC/RRS18, RRC10 and RRC/RRS04 manuals for a detailed description of the local control panel, the way to set-up remote control over IP and for frame related settings and status information.

Remote Control Capabilities

The remote control options are explained in the rack controller (RRC/RRS18/RRC10/RRC/RRS04) manual. The method of connection to a computer using Ethernet is described in the RRC manual.



CHECK-OUT: “SYNAPSE SET-UP” SOFTWARE WILL INCREASE SYSTEM FLEXIBILITY OF ONE OR MORE SYNAPSE FRAMES

Although not required to set up a Synapse frame, you are strongly advised to use a remote personal computer or laptop PC with the Synapse set up software as this increases the ease of use and understanding of the modules.

2 Unpacking and Placement

Unpacking

The Axon Synapse card must be unpacked in an anti-static environment. Care must be taken NOT to touch components on the card – always handle the card carefully by the edges. The card must be stored and shipped in anti-static packaging. Ensuring that these precautions are followed will prevent premature failure from components mounted on the board.

Locating the card

The Synapse card can be placed vertically in an SFR18 frame or horizontally in an SFR04 frame. Locate the two guide slots to be used, slide in the mounted circuit board, and push it firmly to locate the connectors.

Correct insertion of card is essential as a card that is not located properly may show valid indicators, but does not function correctly.

REMARK: On power up all LEDs will light for a few seconds, this is the time it takes to initialise the card.

3 A Quick Start

When Powering-up

On powering up the Synapse frame, the card set will use basic data and default initialisation settings. All LEDs will light during this process. After initialisation, several LEDs will remain lit – the exact number and configuration is dependant upon the number of inputs connected and the status of the inputs.

Default settings



In its default condition, the TXT06 will act as a distribution amplifier on the two processed outputs that will both generate a blue screen. No text is displayed. (This has to be filled out, in the identity /user label) The SDI format is set to automatic.

Changing parameters and settings

The front panel controls or the Synapse Set-Up Software can be used to change settings. An overview of the settings can be found in chapter 5, 6 and 7 of this manual.

Front Panel Control

Front Panel Display and Cursor



Settings are displayed and changed as follows;

Use the cursor ‘arrows’ on the front panel to select the menu and parameter to be displayed and/or changed.


- Press ► To go forward through the menu structure.
- Press ◀ To go back through the menu structure.
- Press ▲ To move up within a menu or increase the value of a parameter.
- Press ▼ To move down through a menu or decrease the value of a parameter.

REMARK: Whilst editing a setting, pressing ► twice will reset the value to its default.

Example of changing parameters using front panel control

With the display as shown below


```
RRC18 [Select Card]
>S01=TXT06
```



Pressing the ► selects the TXT06 in frame slot 01.

The display changes to indicate that the TXT06 has been selected. In this example the Settings menu item is indicated.

```
TXT06[Select Menu]
>Settings
```




Pressing the ► selects the menu item shown, in this example Settings.

(Pressing ▲ or ▼ will change to a different menu eg Status, Events).

The display changes to indicate that the TXT06 Settings menu item SDI-Format has been selected and shows that its current setting is Auto.

```
TXT06 [Settings]
>SDI-Format=Auto
```




Pressing the ► selects the settings item shown, in this example SDI-Format.

(Pressing ▲ or ▼ will change to a different setting, eg Mode, H-Delay).

The display changes to indicate that the SVD10 Edit Setting menu item SDI-Format has been selected.

```
TXT06[Edit Setting]
SDI-Format>Auto
```



To edit the setting of the menu item press ▲ or ▼.

All menu items can be monitored and/or changed in this way. Changing a setting has an immediate effect.

Synapse SetUp Software

Synapse SetUp Software can be used to change the settings of Synapse modules from a PC, either locally or remotely. The software enables communication based on TCP/IP between the setup PC and Synapse frames/modules.

Each Synapse frame is addressed through its rack controller's unique IP address, giving access to each module, its menus and adjustment items. The Synapse SetUp software has access to data contained within the Synapse module and displays it on a GUI. The software has an intuitive structure following that of the module that it is controlling.

Having selected the desired Frame and Module from the GUI Synapse Network View, select the menu item that you wish to open. Opening the menu item gives a complete list of available properties with their associated Value.

For example to change a setting e.g. SDI-Format, select SDI-Format from the list of settings by 'double clicking' to open a dialogue box. The dialogue box allows parameters to be changed or set to default value. On completion close the dialogue box.

Menu Structure Example

Slot	Module	Item	Parameter	Setting
▲				
▲				
S02		Identity		
▲				
S01	TXT06	Settings	SDI-Format	Auto
▼				
S00	RRC18	Status	Mode	625
		▼		▼
		Events	Ref-Input	525
			▼	
			H-Delay	
			▼	

REMARK: Further information about Front Panel Control and Synapse Set Up Software can be obtained from the RRC18 and RRC04 operational manuals.

4 The TXT06 Card

Introduction

The TXT06 is a distribution amplifier that can generate a blue screen with text field on processed outputs (BNC 2 to 7).

This text field can contain a maximum of 16 characters, and relates to the user label.

The position is fixed in the centre of the screen; the height of the text is 100 lines.

5 Settings Menu

Introduction	<p>The settings menu displays the current state of each setting within the TXT06 and enables the item to be changed or adjusted.</p> <p>Settings can be changed using the front panel of the Synapse frame (SFR18 or SFR04) or Synapse SetUp software.</p> <p>Please refer to chapter 3 for information on the Synapse front panel control and Synapse SetUp software.</p>
SDI-Format	<p>The <code>SDI-format</code> menu item selects the input video standard, 525, 625 and <code>Auto</code> can be selected. In <code>Auto</code> mode care must be taken when the H-Delay is outside the 525 limits. When the input is disturbed temporarily, the card switches over from 625 to 525 and back.</p>
NOTE:	<p>The on-screen displays are available on all outputs 2 to 7 (SDI processed).</p> <p>See connector panel in chapter 10.</p>
OSD-Label	<p>OSD-Label (user defined label) is the label as shown in the card IDENTITY/ USER LABEL. (With a maximum of 16 characters). This label appears in the centre of the screen.</p> <p>ON shows the label.</p> <p>OFF blanks the label.</p> <p>Default setting is ON.</p>
EDH-Det	<p>With this setting it is possible to choose whether the EDH detection should be done in <code>FULL_FIELD</code> (Full-F) or in the <code>ACTIVE_P</code> (Active_p).</p>

6 Status Menu

Introduction	The status menu indicates the current status of each item listed below.
SDI-Input	This status item indicates if a valid serial digital video signal is present at the input. NA is input not present , SDI is input present.
Format	625 and 525 line standards can be detected as the valid input signal format – 625/50 and 525/60 are recognised as valid inputs.
EDH- Stat	<p>OK is indicated if the status of the detected EDH does not indicate errors.</p> <p>UES is shown if an EDH data block is not present.</p> <p>EDA is displayed if an EDH error has previously been detected by another card in the SDI chain.</p> <p>EDH is displayed if a previously undetected EDH error is detected by this device.</p>

7 Events Menu

Introduction	An event is a special message that is generated on the card asynchronously. This means that it is not the response to a request to the card, but a spontaneous message.
What is the Goal of an event?	The goal of events is to inform the environment about a changing condition on the card. A message may be broadcast to mark the change in status. The message is volatile and cannot be retrieved from the system after it has been broadcast. There are several means by which the message can be filtered.
TXT06 Events	The events reported by the TXT06 are as follows;
Announcements	Announcements is not an event. This item is only used for switching the announcement of status changes on/off. 0=off, other =on
Input	Input can be selected between 0 .. 255. 0= no event, 1..255 is the priority setting.
EDH status	EDH status can be selected between 0 .. 255. 0= no event, 1..255 is the priority setting.
What information is available in an event?	The message consists of the following items; <ol style="list-style-type: none">1) A message string to show what has happened in text, for example: "INP_LOSS", "REF_LOSS", "INP_RETURN".2) A tag that also shows what happens, but with a predefined number: e.g. 1 (= loss of input), 2 (= loss of reference), 129(= 1+128 = return of input). For a list of these predefined tags see the table on the next page.3) A priority that marks the importance of an event. This value is defined by the user and can have any value between 1 and 255, or 0 when disabled.4) A slot number of the source of this event.
The Message String	The message string is defined in the card and is therefore fixed. It may be used in controlling software like Synapse Set-up to show the event.

The Tag

The tag is also defined in the card. The tag has a fixed meaning. When controlling or monitoring software should make decisions based on events, it is easier to use the tag instead of interpreting a string. The first implementation is the tag controlled switch in the GPI16.

In cases where the event marks a change to fault status (e.g. 1 for Loss of Input) the complement is marked by the tag increased by 128 (80_{hex}) (e.g. 129 (81_{hex}) for Return of Input).

Defining Tags

The tags defined for the TXT06 are:

Event Menu Item	Tag		Description
Announcements	0 or NA	0 or NA	Announcing of report and control values
Input	01 _{hex} =INP_LOSS	81 _{hex} =INP_RETURN	primary input lost or returned
EDH-Status	03 _{hex} =EDH_ERROR	83 _{hex} =EDH_OK	EDH error occurred

The Priority

The priority is a user-defined value. The higher the priority of the alarm, the higher this value. Setting the priority to Zero disables the announcement of this alarm. Alarms with priorities equal or higher than the Error Threshold setting of the RRC will cause the error LED on the Synapse rack front panel to light.

The Address

Together with the message string or the tag, the slot number or address of the card is relevant to be able to assign the event to a certain card.

8 LED Indication

Error LED The error LED indicates an error if the internal logic of the SFS10 card is not configured correctly or has a hardware failure.


Input LED This LED indicated the presence of a valid SDI video signal on the input.

Data Error LED This LED indicate two different types of error:

- EDH error

Connection LED This LED illuminates after the card has initialised. The LED lights for 0.5 seconds every time a connection is made to the card.

9 Block Schematic



10 Connector Panel

The TXT06 can be used with the following backplanes: BPL01 and BPL08

!Unused inputs and outputs must be terminated with the correct impedance!

